

Console

COMMANDER[®]
ECHO[™]



Console Highlights

- Wireless, lightweight, compact design (4.66 x 2.61 x 0.96 - length, width, depth; 0.46 lb. weight)
- Large LCD window with easy-to-read characters
- Automatic test sequencing
- Made in the USA
- Gathers, stores and displays data from up to 20 tests from the instrument(s)
- Automatically calculates appropriate statistics
- Rechargeable Lithium-polymer battery for a long life and portable operation
- Measures in pounds, kilograms, Newtons and degrees
- Wireless console is independent of the testing devices allowing the tester to review data during active testing without influencing the patient's level of effort

*Instrument shown with accessories.

†Instruments not shown to scale.

DISTRIBUTED BY



190, Boul. St-Elzéar Ouest
Laval (Québec) H7L 3N3
T 450 669.8985 | 1 800 361.0877
F 450 669.9532 | 1 888 935.7001


www.medicaltronik.ca



JTECH MEDICAL
MEASURING HUMAN PERFORMANCE

© 2012 JTECH MEDICAL MM315_B

The Commander Echo line from JTECH Medical brings advanced levels of sophistication and versatility to portable evaluation and outcome assessment equipment. Only a single console is required for up to 20 testing instruments. The console is wireless and automatically collects data, stores results, computes statistics and prompts you for the next test when testing in a series. The Commander Echo Console also allows you to select tests, delete unwanted information, and more with a simple joystick operation. All these features help you collect and record objective data faster and easier.



1. Test number
2. Rep #
3. Identifies device
4. Side being tested
5. Real-time data displays in units of measurement (pounds, kilograms, Newtons, or degrees)



Included accessories:

- USB Daisy Chain (8WR009)** – Is used to charge up to four (4) Commander Echo devices at once.
- Specified Power Supply (Battery Charger) (PW006)** – Is used with the Daisy Chain, for charging your Commander Echo Console and Commander Echo devices.
- Wrist Lanyard (7AC002)** – Is used to help prevent dropping the Commander Echo Console when carrying the console.